

The Trap Field

- The instructions for activating the Trap machine is shown in the following pictorial.
- Connect machine release cords, cable or remote. This is a twist type plug to prevent machine from becoming unplugged. Turn on pump switch.
- Turn on machine release switch.
- Load machine. Every other stack of clays, the separator rail can be removed for ease of loading targets.
- To shut trap station down, reverse the steps above.

Trap house operation

Step 1



Step 2: Release cables



Connect release cable to machine by twist lock plug in's.

Step 3: Turn on pump motor and release switch to on position



Step 4: Loading targets for Trap machine

